

2、Cassette Type Indoor Unit's Error Indicating:

LED	No error	Flash times every two seconds	Error description
yellow: Timing indicating lamp	It goes on as per the set time, And it flashes when the temperature sensor error occurs	once	the indoor ambient temperature sensor error
		twice	the evaporator temperature sensor error
		three times	the condenser temperature sensor error
		four times	the outdoor ambient temperature sensor error
		five times	the discharge air temperature sensor error
green : Compressor indicating lamp	It goes on/off as the compressor is turned on/off. And it flashes when defrosting or the compressor error occurs	twice	Defrosting
		three times	high pressure protection
		four times	the low pressure protection
		five times	Overload protection
		six times	Discharge high temperature protection
red : Running indicating lamp	It goes on/off as the unit is turned on/off, And it flashes when the indoor unit error occurs	twice	the water overflow protection
		three times	the anti-freezing error
		four times	Anti-high temperature protection